



WHEN ORDERING RE-
PLACEMENTS, STATE SERIAL
NUMBER AND SIZE STAMPED
ON NAME PLATE OF MACHINE
AND DESIGNATE PART BY
BOTH NAME AND NUMBER

- R 100 PINION SHAFT
- R 101 MAIN PINION
- R 102 PINION THRUST COLLAR
- R 103 ROLLER BEARING (PINION END)
- R 104 PINION BEARING RETAINER CAP
- R 105 PINION SHAFT END CAP
- R 106 FLYWHEEL BEARING SPACER RING (INNER)
- R 107 FLYWHEEL BEARING CAGE
- R 108 ROLLER BEARING (FLYWHEEL END)
- R 109 FLYWHEEL BEARING RETAINER CAP
- R 110 FLYWHEEL BEARING SPACER RING (OUTER)

- R 111 FLYWHEEL
- R 112 FLYWHEEL FRICTION SLEEVE
- R 113 FLYWHEEL FRICTION DISC
- R 114 FLYWHEEL FRICTION DISC WASHER
- R 115 FLYWHEEL FRICTION SLEEVE STUD
- R 226 BEARING CAGE LOCK SCREW
- R 227 BEARING LOCK SCREW