


SHEET E-1-B



WHEN ORDERING REPLACEMENTS, STATE SERIAL NUMBER AND SIZE STAMPED ON NAME PLATE OF MACHINE AND DESIGNATE PART BY BOTH NAME AND NUMBER.

- | | | | |
|-----|--|-----|---------------------------------|
| 201 | CRANKSHAFT | 212 | MAIN PINION |
| 202 | CRANKSHAFT SLEEVE-GEAR END | 217 | FLYWHEEL SHAFT |
| 203 | CRANKSHAFT SLEEVE BUSHING -GEAR END | 218 | TIMKEN BEARING -PINION END |
| 204 | CRANKSHAFT SLEEVE - INTERMEDIATE | 219 | HYATT BEARING -FLYWHEEL END |
| 205 | CRANKSHAFT SLEEVE BUSHING-INTERMEDIATE | 223 | BEARING SPACER - PINION END |
| 206 | CRANKSHAFT SLEEVE-CAM END | 227 | BEARING SPACER - PINION END |
| 207 | CRANKSHAFT SLEEVE BUSHING-CAM END | 228 | BEARING RETAINER -PINION END |
| 208 | DIE CLOSING CAM | 229 | BEARING SEAL RING - PINION END |
| 209 | DIE CLOSING CAM RETAINING NUT | 230 | MAIN PINION RETAINER END |
| 210 | TIMER CAM, OR SPROCKET | 231 | BEARING SPACER -FLYWHEEL END |
| 211 | MAIN GEAR | 232 | BEARING SEAL RING -FLYWHEEL END |
| | | 233 | BEARING RETAINER -FLYWHEEL END |