


## SHEET E-1



WHEN ORDERING REPLACEMENTS, STATE SERIAL NUMBER AND SIZE STAMPED ON NAME PLATE OF MACHINE AND DESIGNATE PART BY BOTH NAME AND NUMBER.

- |     |  |     |                                 |
|-----|--|-----|---------------------------------|
| 201 | CRANKSHAFT                             | 212 | MAIN PINION                     |
| 202 | CRANKSHAFT SLEEVE-GEAR END             | 217 | FLYWHEEL SHAFT                  |
| 203 | CRANKSHAFT SLEEVE BUSHING-GEAR END     | 218 | TIMKEN BEARING-PINION END       |
| 204 | CRANKSHAFT SLEEVE - INTERMEDIATE       | 219 | HYATT BEARING-FLYWHEEL END      |
| 205 | CRANKSHAFT SLEEVE BUSHING-INTERMEDIATE | 223 | BEARING SPACER-PINION END       |
| 206 | CRANKSHAFT SLEEVE-CAM END              | 227 | BEARING SPACER-PINION END       |
| 207 | CRANKSHAFT SLEEVE BUSHING-CAM END      | 228 | BEARING RETAINER-PINION END     |
| 208 | DIE CLOSING CAM                        | 229 | BEARING SEAL RING - PINION END  |
| 209 | DIE CLOSING CAM RETAINING NUT          | 230 | MAIN PINION RETAINER END        |
| 210 | TIMER CAM OR SPROCKET                  | 231 | BEARING SPACER-FLYWHEEL END     |
| 211 | MAIN GEAR                              | 232 | BEARING SEAL RING -FLYWHEEL END |
|     |  | 233 | BEARING RETAINER-FLYWHEEL END   |