



WHEN ORDERING REPLACEMENTS
STATE SERIAL NUMBER AND
SIZE STAMPED ON NAME PLATE
OF MACHINE AND DESIGNATE
PART BY BOTH NAME AND
NUMBER

- 301 HEADER SLIDE
- 302 TOOLHOLDER CLAMP
- 303 TOOLHOLDER WEDGE
- 304 FITMAN
- 305 FITMAN CAP
- 306 FITMAN BOLTS
- 307 FITMAN AND CRANKSHAFT BUSHING
- 308 FITMAN THRUST BUSHING
- 309 FITMAN WRIST PIN
- 310 FITMAN WRIST PIN BUSHINGS
- 311 HEADER SLIDE STATIONARY SIDE LINER
- 312 HEADER SLIDE ADJUSTING SIDE LINER
- 313 HEADER SLIDE ADJ. SIDE LINER PLUGS
- 314 HEADER SLIDE ADJ. SIDE LINER NUTS
- 315 HEADER SLIDE RIGHT HAND LIP LINER
- 316 HEADER SLIDE LEFT HAND LIP LINER
- 317 BED LINER FOR HEADER SLIDE RIGHT LIP
- 318 BED LINER FOR HEADER SLIDE LEFT LIP
- 319 HEADER SLIDE EXTENSION TOP LINERS
- 320 HEADER SLIDE EXTENSION SIDE LINERS
- 321 HEADER SLIDE EXTENSION BOTTOM LINERS
- 322 HEADER SLIDE LEFT HAND COVER PLATE
- 323 HEADER SLIDE RIGHT HAND COVER PLATE

- 324 STOCK GAUGE- STRAIGHT
- 325 STOCK GAUGE- OFFSET
- 326 STOCK GAUGE HEAD
- 327 STOCK GAUGE SHAFT
- 328 STOCK GAUGE SHAFT BR'G. CAP- FRONT
- 329 STOCK GAUGE SHAFT BR'G. CAP- REAR
- 330 STOCK GAUGE SLEEVE
- 331 STOCK GAUGE SPRING
- 332 STOCK GAUGE SPRING ROD
- 334 STOCK GAUGE CAM
- 335 STOCK GAUGE CAM ROLLER WITH BUSH.
- 336 STOCK GAUGE CAM ROLLER PIN
- 337 STOCK GAUGE ADJUSTING SLEEVE
- 338 STOCK GAUGE SHAFT COLLAR
- 339 TOOLHOLDER CLAMP STUDS