



WHEN ORDERING RE-  
PLACEMENTS, STATE SERIAL  
NUMBER AND SIZE STAMPED  
ON NAME PLATE OF MACHINE  
AND DESIGNATE PART BY  
BOTH NAME AND NUMBER

- R 116 IDLER SHAFT
- R 117 IDLER GEAR
- R 120 IDLER SHAFT THRUST COLLAR
- R 123 IDLER GEAR BUSHING
- R 124 IDLER SHAFT END CAP

- R 125 INTERMEDIATE SHAFT
- R 126 INTERMEDIATE GEAR
- R 127 INTERMEDIATE PINION
- R 128 INTERMEDIATE PINION BUSHING
- R 129 INTERMEDIATE SHAFT END CAP