



INTERMEDIATE SHAFT

WHEN ORDERING REPLACEMENTS,
 STATE SERIAL NUMBER AND SIZE
 STAMPED ON NAME PLATE OF MACHINE
 AND DESIGNATE PART BY BOTH NAME
 AND NUMBER

- R 116 IDLER SHAFT
- R 117 IDLER GEAR
- R 120 IDLER SHAFT THRUST COLLAR
- R 123 IDLER GEAR BUSHING
- R 124 IDLER SHAFT END CAP
- R 125 INTERMEDIATE SHAFT

- R 126 INTERMEDIATE GEAR
- R 127 INTERMEDIATE PINION
- R 260 INTERMEDIATE SHAFT BUSHING
- R 261 INTERMEDIATE SHAFT BUSHING
- R 280 INTERMEDIATE SHAFT THRUST RING
- R 282 IDLER GEAR SPLIT COLLAR