



WHEN ORDERING RE-
PLACEMENTS, STATE SERIAL
NUMBER AND SIZE STAMPED
ON NAME PLATE OF MACHINE
AND DESIGNATE PART BY
BOTH NAME AND NUMBER

R 116 IDLER SHAFT
R 117 IDLER GEAR
R 120 IDLER SHAFT THRUST COLLAR
R 123 IDLER GEAR BUSHING
R 124 IDLER SHAFT END CAP

R 125 INTERMEDIATE SHAFT
R 126 INTERMEDIATE GEAR
R 127 INTERMEDIATE PINION
R 128 INTERMEDIATE PINION BUSHING
R 130 INTERMEDIATE PINION AND HUB