



WHEN ORDERING RE-PLACEMENTS, STATE SERIAL NUMBER AND SIZE STAMPED ON NAME PLATE OF MACHINE AND DESIGNATE PART BY BOTH NAME AND NUMBER

- R 100 PINION SHAFT
- R 101 MAIN PINION
- R 102 PINION SHAFT THRUST RING
- R 103 ROLLER BEARING (INNER END)
- R 104 INNER BEARING RETAINER CAP
- R 105 PINION SHAFT END CAP THRUST RING
- R 107 FLYWHEEL BEARING CAGE
- R 108 ROLLER BEARING (FLYWHEEL END)
- R 109 FLYWHEEL BEARING RETAINER CAP
- R 220 PINION SHAFT THRUST COLLAR
- R 226 BEARING CAGE LOCK SCREW
- R 227 BEARING LOCK SCREW
- R 299 PINION SHAFT GREASE RETAINER