



WHEN ORDERING REPLACEMENTS, STATE
SERIAL NUMBER AND SIZE STAMPED ON
NAME PLATE OF MACHINE AND DESIGNATE
PART BY BOTH NAME AND NUMBER

- R 100 PINION SHAFT.
- R 101 MAIN PINION.
- R 103 ROLLER BEARING (INNER END).
- R 105 PINION SHAFT END CAP.
- R 106 SPACER (INNER END).
- R 107 BEARING CAGE (FLYWHEEL END).
- R 108 ROLLER BEARING (FLYWHEEL END).
- R 109 BEARING CAGE CAP (FLYWHEEL END).
- R 226 BEARING CAGE LOCK SCREW.
- R 299 PINION SHAFT GREASE RETAINER.
- R 399 BEARING CAGE (INNER END).
- R 400 PINION SHAFT BEARING RETAINER.
- R 401 BEARING RETAINER COVER PLATE.