



WHEN ORDERING REPLACEMENTS STATE SERIAL NUMBER AND SIZE STAMPED ON NAME PLATE OF MACHINE AND DESIGNATE PART BY BOTH NAME AND NUMBER

- |   |   |
|---|---|
| 1201 CRANKSHAFT                                 | 1222 FLYWHEEL CLAMP PLATE                     |
| 1202 CRANKSHAFT RIGHT HAND SLEEVE               | 1223 FLYWHEEL CLAMP BOLTS                     |
| 1203 CRANKSHAFT R. H. SLEEVE BUSHING            | 1224 FLYWHEEL FRICTION PLATES                 |
| 1204 CRANKSHAFT LEFT HAND SLEEVE                | 1225 FLYWHEEL HUB RETAINING PLATE             |
| 1205 CRANKSHAFT L. H. SLEEVE BUSHING            | 1401 BOTTOM KNOCKOUT CAM                      |
| 1206 MAIN GEAR                                  | 1226 K. O. CAM AND BRAKE DRUM RETAINING PLATE |
| 1208 MAIN PINION                                | 1227 TIMER CAM.                               |
| 1209 PINION SHAFT                               |   |
| 1210 MAIN PINION RETAINING PLATE                |   |
| 1211 PINION SHAFT RIGHT HAND ROLLER BEARING (S) |   |
| 1212 PINION SHAFT R. H. BEARING END COLLAR      |   |
| 1213 PINION SHAFT R. H. BEARING SEAL RING       |   |
| 1216 PINION SHAFT LEFT HAND ROLLER BEARING      |   |
| 1217 PINION SHAFT L. H. BEARING SEAL RING       |   |
| 1219 PINION SHAFT L. H. BEARING END COLLAR      |   |
| 1220 FLYWHEEL RIM                               |   |
| 1221 FLYWHEEL HUB                               |   |