



WHEN ORDERING REPLACEMENTS STATE SERIAL NUMBER AND SIZE STAMPED ON NAME PLATE OF MACHINE AND DESIGNATE PART BY BOTH NAME AND NUMBER

- |                                              |                                                 |
|----------------------------------------------|-------------------------------------------------|
| 1201 CRANKSHAFT                              | 1218 PINION SHAFT LEFT HAND BEARING SPACER RING |
| 1202 CRANKSHAFT RIGHT HAND SLEEVE            | 1219 PINION SHAFT LEFT HAND BEARING END COLLAR  |
| 1203 CRANKSHAFT R. H. SLEEVE BUSHING         | 1401 BOTTOM KNOCKOUT CAM                        |
| 1204 CRANKSHAFT LEFT HAND SLEEVE             | 723 DUAL VALVE CAM                              |
| 1205 CRANKSHAFT L. H. SLEEVE BUSHING         |                                                 |
| 1206 MAIN GEAR                               |                                                 |
| 1207 MAIN GEAR RETAINING PLATE               |                                                 |
| 1208 MAIN PINION                             |                                                 |
| 1209 PINION SHAFT                            |                                                 |
| 1210 MAIN PINION RETAINING PLATE             |                                                 |
| 1211 PINION SHAFT RIGHT HAND ROLLER BEARINGS |                                                 |
| 1212 PINION SHAFT R. H. BEARING END COLLAR   |                                                 |
| 1213 PINION SHAFT R. H. BEARING SEAL RING    |                                                 |
| 1214 PINION SHAFT R. H. BEARING SPACER RING  |                                                 |
| 1215 PINION SHAFT SET COLLAR                 |                                                 |
| 1216 PINION SHAFT LEFT HAND ROLLER BEARING   |                                                 |
| 1217 PINION SHAFT LEFT HAND BRG. SEAL RING   |                                                 |