



THE AJAX MANUFACTURING COMPANY  
CLEVELAND, OHIO 44117

20	BASE	508	PITMAN
21	DRAWING ARM	509	PITMAN BUSHING - MAIN EYE
22	DRAWING ARM FULCRUM PIN	510	PITMAN BUSHING - SMALL EYE
23	DRAWING ARM FULCRUM PIN BUSHINGS	518	HUB FOR DRIVEN SPROCKET
24	REMOVABLE PIN FOR DRWG. & INCH. ARMS	519	DRIVEN SPROCKET
25	PIN FOR DRWG. & INCH. ARMS	520	SPROCKET RETAINER WASHER
30	INCHING ARM	521	DRIVING SPROCKET
34	INCHING ARM LIFTER	522	ROLLER CHAIN
35	INCHING ARM LIFTER HANDLE	523	IDLER ROLLER SPROCKET
36	INCHING ARM LIFTER FULCRUM PIN	524	IDLER ROLLER BEARING
43	STRAIGHTENER RODS	525	IDLER ROLLER PIN
44	STRAIGHTENER BRACKET	526	IDLER ROLLER RETAINING CAP
45	GUIDE ROLLERS	527	IDLER ARM
46	PINS FOR GUIDE ROLLERS	528	IDLER ARM FULCRUM PIN
47	COVER PLATES FOR SLIDES	529	EYE BOLT LINK PIN
48	LINERS FOR BASE	530	IDLER ADJ. EYE BOLT
49	BREAKER BOLT FOR DRAWING ARM	531	EYE BOLT SPACER WASHER
50	BACKING BLOCKS FOR GRIP	532	EYE BOLT SWIVEL PIN
51	STATIONARY WEDGE BLOCKS FOR GRIP	533	BUSHINGS FOR ECC. & SPRKT. SHAFT
52	ROLLER CAGES	547	SPRING PLUG FOR ACT. LEVER
53	BOTTOM LINER FOR GRIP BOX	548	SPRING FOR ACT. LEVER
54	CLAMPING RACKS FOR INCH. GRIP SLIDE	549	SPRING ROD FOR ACT. LEVER
55	SCREWS FOR CLAMPING RACKS	550	PITMAN KNOCKOFF NUT
57	PIN - PITMAN TO DRAWING ARM	557	HUB FOR DRIVING SPROCKET
58	STRAIGHTENER ROD BUSHINGS	562	STRAIGHTENER BUSHING HOLDER
59	BREAKER BOLT GUARD PLATES	563	STRN. BRKT. MOUNTING PLATE
503	ECCENTRIC AND SPROCKET SHAFT	564	BUSHINGS FOR GUIDE ROLLERS
504	PIN FOR ECCENTRIC		
505	ECCENTRIC PIN ADJUSTING SCREW		
506	SLEEVE FOR ECCENTRIC PIN		
507	WASHER FOR ECCENTRIC PIN		

100	INCH. FEED SLIDE COMPLETE PARTS 101 TO 107 INCL.	200	INCH. GRIP SLIDE COMPLETE PARTS 201 & 102 TO 106 INCL.
101	INCHING FEED SLIDE	201	INCHING GRIP SLIDE
102	PINS FOR INCHING FINGERS	102	PINS FOR INCH. FINGERS
103	LATCH FOR INCHING FINGERS	103	LATCH FOR INCH. FINGERS
104	LATCH SPRING	104	LATCH SPRING
105	SPRING PLUG FOR INCHING FINGERS	105	SPRING PLUG FOR INCH. FINGER
106	SPRING FOR SPRING PLUG	106	SPRING FOR SPRING PLUG
107	PIN FOR INCHING ARM		

300	DIE SLIDE COMPLETE PARTS 301 TO 308 INCL.	400	GRIP BOX COMPLETE WITH PARTS LISTED BELOW
301	DIE SLIDE	401	GRIP BOX
302	DIE SLIDE COVER	403	HANDLE FOR GRIP BOX
303	DIE SLIDE COVER CLAMP	404	HOLLOW SCREW FOR GRIP BOX
304	DIE SLIDE BUSHING CLAMP	405	SPRING FOR GRIP BOX HOLLOW SCREW
305	DIE SLIDE BUSHING HOLDER	406	SCREWS FOR ROLLER CAGE ACTUATING SPRING
306	DIE SLIDE BUMPING PLATES	407	ROLLER CAGE ACTUATING SPRING
308	DIE SLIDE GASKET	408	PINS FOR GRIP BLOCKS RELEASE
		410	PLUGS FOR ROLLER CAGE SPRING
		411	PIN FOR GRIP RELEASE HANDLE
		417	LOCKSCREWS FOR PLUG

WHEN ORDERING REPLACEMENTS STATE SERIAL NUMBER AND SIZE STAMPED ON NAME PLATE OF MACHINE AND DESIGNATE PART BY BOTH NAME AND NUMBER

THE AJAX MANUFACTURING COMPANY  
CLEVELAND, OHIO 44117