



Ajax

- 611 FEED OPERATING LEVER
- 612 FEED LEVER PIN
- 617 SPRING ROD FOR FEED ROLLS
- 618 SPRING ROD UPPER CLEVIS
- 619 PIN FOR UPPER CLEVIS
- 620 SPRING PRESSURE BAR
- 621 PRESSURE BAR FULCRUM PIN

- 623 GUIDE ROLLER RETAINER PLATE
- 625 FEED ROLL RETAINER WASHER
- 630 FEED ROCK SHAFT
- 631 FEED ROCK SHAFT BUSHINGS (2-REQ'D)
- 632 FEED ROLL HOUSING
- 633 FEED ROLL SHAFT BUSHINGS
- 634 FEED RELEASE SPRING
- 635 GUIDE ROLLER PINS
- 636 TOP FEED ROLL SHAFT JOURNAL
- 637 GEAR FOR TOP FEED ROLL SHAFT
- 638 TOP FEED ROLL SHAFT




THE AJAX MANUFACTURING CO.
CLEVELAND, OHIO 44117

Ajax


- 639 TOP FEED ROLL SHAFT END CAP
- 640 FULC. PIN FOR TOP ROLL FEED SHAFT JOURNAL
- 641 REMOVABLE PIN FOR CLUTCH ARM
- 642 BOTTOM FEED ROLL SHAFT
- 643 CLUTCH RETAINING CAP
- 645 SLEEVE CLAMP WASHER
- 646 FEED ARM SLEEVE
- 648 GEAR FOR BOTTOM FEED ROLL SHAFT
- 649 FEED ARM RETAINER WASHER
- 651 FEED CONNECTING LINK BUSHING - SMALL EYE
- 657 BRAKE DRUM
- 658 BRAKE LINING
- 644 OVER-RUNNING CLUTCH

- 663 FEED CONNECTING LINK
- 664 FEED ARM



- 687 BRAKE ARM
- 688 EYE BOLT PIN
- 689 BRAKE ARM EYE BOLT
- 690 SPRING COLLAR
- 691 SPRING
- 692 SWIVEL PIN
- 693 BRAKE ARM FULC. PIN
- 694 FORWARD FEED GEAR COVER

- 665 FEED CONNECTING LINK BUSHING
- 666 ADJUSTING SCREW FOR FEED
- 667 PRESSURE LEVER CLEVIS
- 668 PRESSURE LEVER CLEVIS PIN
- 669 PRESSURE LEVER FULCRUM PIN
- 670 PRESSURE LEVER BUSHINGS
- 672 CYLINDER FULCRUM PIN
- 673 CYLINDER FOR FEED ROLLS
- 674 CYLINDER CLEVIS
- 676 CYLINDER CLEVIS PIN
- 677 PRESSURE LEVER FOR FEED ROLLS
- 678 SPRING
- 679 WASHER
- 680 DRIVING PLATE
- 681 INNER CLAMP RING
- 682 FRICTION DISCS
- 683 OUTER CLAMP PLATE
- 684 OVER-RUNNING CLUTCH
- 685 DISC SPRINGS
- 686 SPACER



WHEN ORDERING REPLACEMENTS STATE
SERIAL NUMBER AND SIZE STAMPED ON
NAME PLATE OF MACHINE AND DESIGNATE
PART BY BOTH NAME AND NUMBER

THE AJAX MANUFACTURING CO.
CLEVELAND, OHIO 44117